


REPAIR LIST OF STAR ZEPHYR WINDMILL, 8 FOOT WHEEL

This repair list covers parts for all Model 37 mills of No. 83 or 84 series, and can be used for mills with No. 81 or 82 series. When ordering repairs for Star Zephyr Model 37 windmills the SERIAL NUMBER found on the small plate attached to the hood should be given, as well as the number and description of part wanted.

The series number gives us the size and equipment of your windmill but be sure to give us the name, number and description of part you are needing, so there will be no error in filling your order or else loss of time in writing for more information.



**FLINT & WALLING
MFG. CO.
KENDALLVILLE, IND.**

Symbol	Description of Part	List Price	Symbol	Description of Part	List Price
1837	Main frame	\$11.50	5484	Brake lever casting	\$.15
2837	Drive shaft cap for Roller bearing	.40	55837	Brake rod and nut	.25
6837	Drive shaft cap for Plain bearing	.40	34837	Bumper rod and nuts	.25
37837	Cover galvanized	2.75	60837	Bumper spring	.10
	Brass nut for cover (3/4")	.15	74837	Bumper rod pin	.20
28837	Drive shaft for Plain bearing	1.65	44837	Gov. spring	.75
29837	Drive shaft for Roller bearing	1.65	36837	Gov. spring bracket and pin	.75
	Roller bearing for Drive Shaft (1 1/4")	2.00	67837	Gov. spring adjusting rod and nuts	.25
4684A	Cast bearing for drive shaft	.75	69837	Gov. spring eye bolt and nuts	.15
	Drive shaft key	.15	19837	Pullout pipe, swivel, bar and chain	1.25
	Oil ring	.05	2382	Sheave	.20
70837	Drive shaft cap lock ring	.30	2484	Sheave guard	.15
71837	Long separator for Roller bearing	.25	32837	Bottom cap	.35
72837	Short separator for Roller bearing	.15	40837	Rudder hinge pin	.30
73737	Locking bar	.10	61837	Rudder hinge pin bushing	.30
3837	Crank shaft case for Roller bearing	1.25	66837	Pullout lever for Steel tower	1.50
584A	Crank shaft case for Plain bearing	1.40	66837W	Pullout lever for Wood tower	1.50
	Crank shaft Roller bearing (3/4")	2.00	68837	Pump rod guide and bolts	.40
4784A	Crank shaft Babbitt bearing	.40	1484	Bed plate for Steel tower	.75
3084	Crank bolt & nut Plain bearing	.50	1584	Bed plate top flange	.75
30837	Crank bolt & nut Roller bearing	.50		Bed plate balls each	.03
984	Gear for Plain bearing	1.65	16837	Truing spider for Steel tower	.75
9837	Gear for Roller bearing	1.65		Truing spider grease cap	.10
1084	Pinion	.65		Oil level oil cup	.20
4837	Pitman	.90		Rudder	4.50
8837	Crosshead	1.25		Rudder stem	4.50
62837	Crosshead pin	.25		Wheel arms per set (5)	5.25
31837	Guide rod and nut	1.50		Wheel rims inside per set (5)	1.00
7887	Guide rod brace casting	.30		Wheel rims outside per set (5)	1.50
63837	Guide rod brace	.25		Wheel fan each	.60
39837	Pump rod complete	1.00		Wheel fan bracket	.10
64837	Swivel stud	.75		Wheel sections per set (5)	16.00
65837	Castellated swivel nut	.25		Wheel sections each	3.75
2584	Oil pump plunger, ball and cap	.45		Wheel bolts per set	1.50
2684	Oil pump cylinder, ball and bushing	.85		Engine parts assembled, Roller bearing	38.50
11837	Oil shield	.10		Engine parts assembled, Plain bearing	33.00
76837	Oil guard	.15		Engine parts as shipped, Roller bearing	45.50
18837	Wheel hub	3.30		Engine parts as shipped, Plain bearing	40.00
3384A	Brake band and stud	.40			

ALWAYS GIVE THE SERIES NUMBER OF YOUR WINDMILL